



Wreath / Garland

INSTRUCTIONS GUIDE

FOR INDOOR AND OUTDOOR USE

attention

Class A Disclaimer: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Please note that changes or modifications of this product not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic precautions should always be followed including the following:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

- Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
- This seasonal use product is not intended for permanent installation or use.
- Do not mount or place near gas or electric heaters, fireplaces, candles or other similar sources of heat.
- Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- Do not let lamps rest on the supply cord or on any wire.
- Unplug the product when leaving the house, or when retiring for the night, or if left unattended.
- This is an electric product – not a toy! To avoid risk of fire, burns, personal injury and electric shock it should not be played with or placed where small children can reach it.
- Do not use this product for other than its intended use.
- Do not hang ornaments or other objects from cord, wire, or light string.
- Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
- Do not cover the product with cloth, paper or any material not part of the product when in use.
- The lamps of this product are not replaceable. Do not attempt to change or modify the lamps.
- Read and follow all instructions that are on the product or provided with the product.
- The controller and remote controller (if included) can only be used with this product.

SAVE THESE INSTRUCTIONS.

⚠ WARNING!

1. This product may potentially trigger seizures for people with photosensitive epilepsy when using the motion effect light modes.
2. The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.
3. Do not connect the chain to the supply while it is in the packing.
4. The lamps are not replaceable.
5. Do not interconnect parts of this lighting chain with parts of another manufacturer's lighting chain.
6. Interconnection shall be made only by the use of the supplied connectors. Any open ends must be sealed-off before use.
7. When storing the product, carefully remove the product from wherever it is placed, including trees, branches, or bushes, to avoid any undue strain or stress on the product conductors, connections, and wires.
8. The external flexible cable or cord of this luminaire can not be replaced; if the cord is damaged, the luminaire shall be destroyed.
9. To reduce the risk of fire and electric shock:
 - a) Use only power adapter supplied with this product, using a different adapter will damage the lights and cause fire, electrical shock hazards.
 - b) Do not install on trees having needles, leaves or branch covering of metal or materials which look like metal.
 - c) Do not mount or support strings in a manner that can cut or damage wire insulation.



The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal.


Technical Specifications

Power supply: see label


Modulation Technique	Frequency Range	Maximum EIRP
Bluetooth	2402-2480 MHz	9.06 dBm
BLE	2402-2480 MHz	8.42 dBm
WIFI	2412-2472 MHz / 2422-2462 MHz	16.76 dBm

physical setup

1.



2.




1. Place your Twinkly Garland / Wreath at your desired spot.
2. Plug the power adapter in an AC outlet and see the lights turn on.

controller


- CONTINUOUS GREEN: Direct Wi-fi mode, connected
 - FLASHING GREEN: Direct Wi-fi mode, no device connected
 - CONTINUOUS BLUE: Home Wi-fi network mode, connected
 - FLASHING BLUE: Home Wi-fi network mode, connection in progress
 - FLASHING RED: Home Wi-fi network mode, unable to connect
-

- LIGHT BLUE: SETUP MODE (Bluetooth ON)
 - YELLOW: Firmware Update in progress
 - CONTINUOUS RED: General error
-


- FLASHING WHITE: Reset procedure in progress




preset effects




RAINBOW




SNOW



UPDOWN




FIREWORKS



GLOW

Light arrangements vary by models




Twinkly comes with 5 preset effects that may be used without downloading the app. Simply plug in the light string to a power outlet, then press the button on the controller to switch between the 5 preset effects.

app download & setup twinkly


1.



2.







3.



1. Go to App Store/Google Play Store. Download and install the Twinkly app.
2. Launch Twinkly app.
3. Select **GENERATION II** controller for your tree. Follow the setup process on the app.

Note: All app illustrations in this document are a mere representation of the functionality and may vary from the actual app visuals.


connection modes



Twinkly uses Bluetooth for the setup process only. Wi-fi connection is required for operation. You can use:

- A. **Home Wi-fi network connection (recommended):**
Connect with your home/office WiFi from the list of available networks.
- B. **Direct Wi-fi connection:**
Select "Twinkly_xxxxxx" WiFi from the list of available networks. Password:
Twinkly2019
(NOTE: the internet on your phone will not be available in this case)

mapping



Map the layout of your decoration to unlock the full potential of your Twinkly lights like advanced effects, drawing and many upcoming features.

online manual




Browse, play and edit effects



Gallery



Create new effects





Group multiple devices together



Download new effects



mapping tips




Note: For best results, avoid reflective surfaces behind the tree, keep the mobile camera steady during the process and ensure a moderate ambient light (not too dark).

choose effects


1.




2.



3.



4.



1. Open the Effects Gallery.
2. Select the desired effect to see the real-time preview on your Twinkly set-up.
3. Swipe left or right to browse effect.
4. Tap **"Apply"** to store the effect and play continuously.

Note: App user interface may change due to technical updates and improvements.

troubleshooting

Q THE LIGHTS DO NOT SWITCH ON

- Check that the power adapter is plugged in and that the controller is correctly connected to the device
- Check that the LED status indicator on the controller is lit
- Briefly press the button on the controller
- If this doesn't work, unplug the power adapter, wait 30 seconds and plug in again

Q THE LED INDICATOR IS LIGHT BLUE, BUT MY SMARTPHONE CANNOT FIND TWINKLY

- Unplug the power adapter, wait 30 seconds, plug it in again and repeat Configuration procedure
- If this does not work, try to Reset (see Reset procedure below)

Q THE LIGHTS TURNED ON BUT LIGHT EFFECTS ARE FROZEN.

- Briefly press the button on the controller
- If this does not work, unplug the power adapter, wait 30 seconds and plug it in again

If you need any assistance, email us at warranty@polygroup.com


Q TWINKLY SETUP WAS SUCCESSFUL, BUT THE LIGHTS DON'T RESPOND TO COMMANDS

- Within the Twinkly application, open "Devices" and check that the Twinkly device is selected
- If this does not work, stop the Twinkly application and launch it again
- If this does not work, try to Reset (see Reset procedure below)
- If this does not work, delete the Twinkly application from your smartphone, then download the latest version from AppStore or Google Play Store

Q HOW CAN I CONNECT TWINKLY WITHOUT HOME Wi-fi NETWORK?

- Open Wi-fi settings on your smartphone
- Find and select "Twinkly_XXXXXX" network
- Enter the Wi-fi password "**Twinkly2019**" and ensure that the "Twinkly_XXXXXX" network is connected

reset twinkly



1. Unplug Twinkly from the power socket. Press and hold the controller button.
2. While holding the button, plug in Twinkly.
3. Keep holding the button until all LEDs turn red, then release the button.



Polygroup Evergreen Limited
Unit 606, 6th Floor, Fairmont House,
8 Cotton Tree Drive,
Central, Hong Kong

To know more about your twinkly and its other cool features, please visit:



www.polygroup.com/twinkly